



SewWhat User Manual

V4.4.1



FEBRUARY 18, 2013

S & S COMPUTING
OAK RIDGE, TN 37830

Table of Contents

Introduction	1
Getting Started	1
Contacting Us	2
Frequently Asked Questions	2
Menus	4
File menu commands	4
Edit menu commands	4
View menu commands	4
Tools menu commands	5
Options menu commands	5
Window menu commands	5
Help menu commands	6
File Commands	7
New	7
Open	7
Merge	7
Close	7
Save	8
Save As	8
Email	8
Print	8
Print Preview	9
Printer Setup	9
Page Setup	9
Exit	10
Edit Commands	11
Undo	11
Delete Threads	11
Join Threads	11
Cut	12
Copy	12
Paste	12
All Objects	13
Next Object	13
Previous Object	13
View Commands	14
Jumps	14
Grid Lines	14
Grid Labels	14
Stitch Points	14
Texture	14
Album Icons	14
Main Toolbar	15
Sew/Show Bar	15
Status Bar	15
Rotation Bar	15
Tools Commands	16
Batch Conversion	16
Create D1 Floppy	16

Sew Lettering	17
Sew and Show	19
Center Pattern	19
Fabric Color	20
Zoom In	20
Zoom Out	20
Options Commands	21
Album Filter	21
D1 Drives.....	21
File Save	21
Grid.....	21
Hoop Size.....	21
Image	22
Units	22
Windows Commands.....	23
New	23
Cascade	23
Tile.....	23
1, 2, ... command.....	23
Help Commands.....	24
Tip of the Day	24
Help Topics	24
Auto-Update	24
About SewWhat.....	24
Change (History) Log	24
Sewing Topics	25
Resize	25
Rotate.....	25
Reflect	25
Dialogs.....	26
File Open.....	26
File Save As	27
Print	27
Printer Setup	27
Thread Color	28
Toolbars.....	29
Main Toolbar	29
Status Bar.....	30
Sew-and-Show	30
Title Bar	31
Scroll Bars	31
Print Preview	31
Rotation	32
Thread Color	32
Miscellaneous	33
Context Help.....	33
Purchase SewWhat.....	33



Introduction

Getting Started

Welcome to the **SewWhat!** embroidery file editor and conversion tool. You may use it to [merge](#), [rotate](#), and [resize](#) (to a limited degree) existing embroidery patterns, as well as convert from one embroidery format to another. [Batch conversion](#) of large numbers of embroidery files between different formats is also available. Additional information about using **SewWhat!** is available by accessing the [Tip of the Day](#) feature at any time.

The **SewWhat!** screen is shown below. The title bar displays information about the file that is currently open. Below the title bar is the menu bar containing drop-down menu commands for various features that control your interaction with the application. (Links to descriptions of the menu commands may be found in [FAQ](#).) Below the menu is the main **SewWhat!** [toolbar](#), which contains iconic buttons that can be clicked to implement many of the menu commands.

Also shown is the [rotation](#) toolbar for reflecting and rotating the selected pattern (a pattern is "selected" by left-clicking on it in the workspace). Below the main toolbar is the [Sew and Show](#) toolbar. This is used to emulate an actual stitch-out of the pattern on your screen.

The remaining work area of the **SewWhat!** screen is divided into two panels consisting of the main panel (or view) and an information panel. In the figure below, the embroidery file "Bearina.art" has been [opened](#) and is displayed in the main workspace. The [hoop](#) associated with the pattern is shown, together with optional [grid lines](#). You may also open a **SewWhat!** editing session by starting the [lettering](#) editor, even without importing an existing embroidery file.


The various tools available for editing embroidery files are described in the [Edit](#) and [Tools](#) menus.

Once your editing session is completed (or at various time during an editing session), you should save your work to a new or existing file, using the [File Save](#) command.

The information panel is located to the right of the workspace (where embroidery files are displayed and edited). It may be toggled from the [View](#) menu to display either the information shown below or an [album icon](#) view of the files in the present working folder.

In the figure below, the information panel contains detailed information about the file, including the number of stitches for each thread and the total thread length. In addition, graphical information about the length distribution of threads may also be shown. Note that the user can move or resize this graph anywhere within the info panel. The information in this panel is updated whenever the file is edited in the work pane or when a new file is opened. To view information about a single thread, click either the [next](#) or [previous](#) object buttons to scroll through the list of threads in the pattern.

The relative sizes of the panels can be changed by dragging the vertical separator bar with the mouse.



Contacting Us

Any questions or comments regarding **SewWhat** should be sent to the S & S Computing support email:

support@sandscomputing.com

Frequently Asked Questions

How To . . .

- [Resize a pattern](#)
- [Merge a pattern](#)
- [Change Thread Color](#)
- [Purchase SewWhat](#)

Menus

- [File Menu](#)
- [Edit Menu](#)
- [View Menu](#)

[Tools Menu](#)
[Options Menu](#)
[Window Menu](#)
[Help Menu](#)



Menus

File menu commands

The File menu offers the following commands:

New	Creates a new blank sewing pattern file.
Open	Opens an existing sewing pattern file.
Merge	Merge a pattern file from disk with the presently active (opened) file.
Close	Closes the presently active pattern file.
Save	Saves an opened pattern file, using the same file name.
Save As	Saves an opened pattern file to a specified file name.
Email	Email active pattern.
Print	Prints the pattern and design information.
Print Preview	Displays the pattern on the screen as it would appear printed.
Page Setup	Selects printing options.
Exit	Exits SewWhat! application.

Edit menu commands

The Edit menu offers the following commands:

Undo	(undo) previous editing operation.
Del Threads	Deletes threads based on length or number of stitches.
Join Threads	Joins threads of a given color.
Cut	Deletes presently selected pattern from the document and moves it to the clipboard.
Copy	Copies presently selected pattern from the document to the clipboard.
Paste	Pastes a pattern from the clipboard into the document.
All Objects	All objects (threads) available for editing.
Next Object	Makes next (thread) object available for editing.
Prev Object	Makes previous (thread) object available for editing.

View menu commands

The View menu offers the following commands:

Jumps	Displays Jump-stitch Dialog for adjusting appearance of jump stitches on screen.
Grid Lines	Shows or hides grid lines useful for positioning pattern.
Grid Labels	Shows or hides grid labels for the grid lines (only visible when grid lines are displayed).
Stitch Points	Shows or hides stitch end points.
Texture	Displays the pattern on screen (and in print) in a textured, 3D appearance.
Album Icons	Toggles between the album icon view (checked) and the info-pane view



	(unchecked, the default).
Main Toolbar	Shows or hides the main toolbar.
Sew/Show Bar	Shows or hides Sew and Show toolbar.
Status Bar	Shows or hides the status bar.
Rotation Bar	Shows or hides the pattern rotation toolbar.

Tools menu commands

The Tools menu offers the following commands:

Batch Convert	Begin batch conversion dialog.
Create D1 Floppy	Write or modify a Designer 1 floppy diskette or create a D1 Zip file archive.
Sew Lettering	Insert lettering/monograms into an embroidery pattern.
Sew & Show	Simulates stitches sewn in real time.
Center Pattern	Center pattern in hoop.
Fabric Color	Display fabric color in hoop.
Zoom In	Magnifies pattern on screen.
Zoom Out	Reduces size of pattern on screen.

Options menu commands

The Options menu offers the following commands:

Album Filter	Select file type(s) to display when Album Icon view is in effect.
D1 Options	Select the default floppy drive for writing D1 files and the directory for storing zipped D1 files.
File Save	Select options to be in effect when saving embroidery files.
Grid	Select the thickness and color of the grid lines displayed on the screen.
Hoop Size	Select hoop size and position it on the screen.
Image	Set quality settings for JPEG images saved from SewWhat!.
Units (Length)	Set measurement units (metric or American) for displaying lengths in SewWhat!

Window menu commands

The Window menu offers the following commands, which enable you to arrange multiple views of multiple documents in the application window:

New Window	Creates a new window that views the same document.
Cascade	Arranges windows in an overlapped fashion.
Tile	Arranges windows in non-overlapped tiles.
Window 1, 2, ...	Goes to specified window.



Help menu commands

The Help menu offers the following commands, which provide you assistance with **SewWhat**:

[Tip of the Day](#)

Displays a useful suggestion for using **SewWhat**.

[Help Topics](#)

Offers you an index to topics on which you can get help.

[AutoUpdate](#)

Toggles on/off the auto-update feature in **SewWhat**.

[About SewWhat](#)

Displays the version number of this application, as well as helpful Web addresses related to the development of this software.

[Change \(History\)](#)

[Log](#)



File Commands

New

Use this command to create a new document (which will be saved as a sewing pattern file) in **SewWhat**. You can open an existing document with the [Open command](#).

Shortcuts

Toolbar:
Keys:



CTRL+N

Open

Use this command to open an existing pattern file in a new window. You can open multiple documents at once. Use the Window menu to switch among the multiple open documents. See [Window 1, 2, ... command](#).

When you use this command, **SewWhat** displays the [File Open dialog box](#) so you can select the pattern file(s) to open.

Alternatively, you can open an existing document by selecting it from the most recently used (MRU) file list in the File menu, if it was recently opened.

You can create new blank documents with the [New command](#).

Shortcuts

Toolbar:
Keys:



CTRL+O

Merge

Use this command to merge a pattern from an existing (but unopened) embroidery file with the presently active pattern. This appends the new pattern to the end of the design in the active window. Use [paste](#) to copy a pattern from already opened file into the present pattern.

Shortcuts


Keys: CTRL+M

Close

Use this command to close all windows containing the active document. **SewWhat** suggests that you save changes to your document before you close it. If you close a document without saving, you lose all changes made since the last time you saved it. Before closing an untitled document, **SewWhat** displays the [Save As dialog box](#) and suggests that you name and save the document.



You can also close a document by using the Close icon on the document's window, as shown below:



Save

Use this command to save the active document to its current name and directory. When you save a document for the first time, **SewWhat** displays the [Save As dialog box](#) so you can name your document. If you want to change the name and directory of an existing document before you save it, choose the [Save As command](#).

Shortcuts

Toolbar:
Keys:



CTRL+S

Save As

Use this command to save and name the active document. **SewWhat** displays the [Save As dialog box](#) so you can name your document.

To save a document with its existing name and directory, use the [Save command](#).

Email

Use this command to send the active pattern to someone via Email.

Shortcuts

Toolbar:



Print

Use this command to print a **SewWhat!** document. This command presents a [Print dialog box](#), where you may specify the range of pages to be printed, the number of copies, the destination printer, and other printer setup options. When the Info Pane is selected in the View menu, then the pattern displayed in the workspace, together with the information summary, will be printed. When the Album (or Icon) view is selected (by unchecking Info Pane on the view menu), an album of all the embroidery files in the present directory will be printed.



Shortcuts

Toolbar:
Keys:



CTRL+P

Print Preview

Use this command to display the active document as it would appear when printed. When you choose this command, the main window will be replaced with a print preview window in which one or two pages will be displayed in their printed format. The [print preview toolbar](#) offers you options to view either one or two pages at a time; move back and forth through the document; zoom in and out of pages; and initiate a print job.

Printer Setup

Use this command to select a printer and a printer connection. This command presents a [Print Setup dialog box](#), where you specify the printer and its connection.

Page Setup

The following options allow you to select the page properties that will effect how the **SewWhat!** screen will be printed.

Edit View

Album

Click this button to edit the **Album Layout** items. Here, you can enter the number of columns and rows for displaying the album icons. The page preview shows how the margin and column/row selections will affect the printed document. Also, check the box beside "Include Zip Files" if you wish to view embroidery files in the present directory that are in Zip archive files. This option will slow down the printing (and display) of the icon view if there are many archived files.

Design

Click this button to edit the **Design Layout** items. You can choose to combine the design and thread information on a single page, or to print them separately. If a pattern is too large to fit onto a single page, then choosing the "separate" option will allow the design to be automatically split over several pages.

Paper Size

Select the size of paper that the document is to be printed on.

Paper Source

Some printers offer multiple trays for different paper sources. Specify the tray here.

Orientation

Choose Portrait or Landscape.

Margins

Enter the page margins here.

Printer

Displays a dialog box for selecting the printer you want to use. Choose the Default Printer, or choose the Name option and select one of the currently installed printers shown in the box. You install printers and configure ports using the Windows Control Panel. Choose the Properties option to further refine the printer properties.

Exit

Use this command to end your **SewWhat** session. You can also use the Close command on the application Control menu. **SewWhat** prompts you to save documents with unsaved changes.

Shortcuts

Mouse: Click the application's Exit (close) menu button.



Keys: ALT+F4

Edit Commands

Undo

Use this command to reverse the last editing action, if possible. The Undo command is dimmed on the menu if there are no actions to reverse. In SewWhat!, the following operations may be undone:


<i>Undo Operation</i>	<i>Effect of Undo</i>
Merge	pattern deleted
Delete pattern or object	pattern or object restored
Color change	thread color restored
Move, scaled rotate	position, size, orientation pattern or object restored

Shortcuts

Toolbar: 
Keys: CTRL+Z


Delete Threads

Choose this option from the Edit menu to popup a dialog for deleting threads from your design. Threads may be deleted either based on the number of stitches and/or the length of thread in a particular color.



Join Threads

Choose this option from the Edit menu to popup a dialog for joining threads of the same color in your design. Threads may be joined either based on being adjacent or by specifying their number on the thread tool bar.



Cut

Use this command to remove the currently selected pattern from the document and put it on the clipboard. This command is unavailable if there is no data currently selected.

Cutting data to the clipboard replaces the contents previously stored there.

Shortcuts

Toolbar:
Keys:



CTRL+X

Copy

Use this command to copy the selected pattern onto the clipboard. This command is unavailable if there is no pattern selected.

Copying data to the clipboard replaces the contents previously stored there.

Shortcuts

Toolbar:
Keys:



CTRL+C

Paste

Use this command to insert a copy of the pattern in the clipboard at the insertion point. This command is unavailable if the clipboard is empty. A bitmap of the pattern is also stored in the clipboard, allowing you to paste the clipboard contents into other standard applications, such as a word processor.

Shortcuts

Toolbar:





Keys: CTRL+V

All Objects

This is activated by default. Threads (objects) are grouped into patterns. By left-clicking with the mouse anywhere within a pattern, the entire pattern can be edited (deleted, resized, moved, reflected, scaled). In contrast, by selecting the [next object](#) (or [previous object](#)) button or menu item, individual thread objects can be edited.

Shortcuts

Toolbar:
Keys:



CTRL+A

Next Object

When this button is activated, the user can select an individual thread object for customized editing. This is useful, for example, if only certain (but not all) thread colors require removal or resizing. Pressing this button scrolls through all the thread colors in increasing order of appearance on the thread selection bar.

Shortcuts

Toolbar:
Keys:



CTRL+N

Previous Object

See the description of the [next object](#) option. In contrast to the next object button, pressing this button scrolls through the thread colors backwards.

Shortcuts

Toolbar:
Keys:



CTRL+R



View Commands

Jumps

This menu launches a dialog box which allows the user to choose the manner in which jump stitches (needle-up) are viewed on screen. The default is for these stitches to be hidden, but the user can override this behavior and show the jumps as dashes or thick lines to distinguish them from the ordinary (needle-down) stitches.

Grid Lines

Grid lines can be shown (or hidden) to help place a pattern accurately within the hoop. Use the [grid options](#) dialog to set the spacing of the grid lines (in units of mm or inches).

Grid Labels

This View menu item is used to display (checked) or hide (unchecked) labels for the [grid lines](#).

Stitch Points

This View menu item displays (checked) or hides (unchecked) the end points for each stitch. This is useful for locating a particular stitch in the pattern. You may have to resize the pattern ([magnify](#) the on screen display) to see the stitch points.

Texture

This View menu item can be selected to display the stitched pattern on screen (and in print mode) in a textured (sometimes called "3D") appearance.

Album Icons

This View menu item toggles the information pane, which shows pattern information for the presently active pattern (information pane), and the icon (or album) view, which displays thumbnails of the embroidery files in the present directory. (The present directory is the one in which the last file was opened by **SewWhat!**) The album (icon) view is useful for a number of purposes:

1. it gives an iconic display of the embroidery files in the present directory
2. it provides a graphical (point and click) method to [merge](#) existing embroidery files with the present pattern. By first selecting a New file from the [File menu](#), the icon of the pattern file can be loaded into a new **SewWhat!** window.

The choice of Info Pane or Album (Icon) view also determines what will be [printed](#). The number of



rows and columns that will be printed can be set in the [Page Setup](#) dialog. There, it is also possible to choose whether or not to display embroidery files that are stored in Zip-archived files.

Shortcuts



Toolbar:

Main Toolbar

Use this command to display and hide the main [Toolbar](#), which includes buttons for some of the most common commands in **SewWhat!**, such as File Open. A check mark appears next to the menu item when the Toolbar is displayed.

Sew/Show Bar

Use this command to display and hide the [Sew and Show toolbar](#), which includes buttons for controlling the stitching feature of **SewWhat**. A check mark appears next to the menu item when the Toolbar is displayed.

Status Bar

Use this command to display and hide the [Status Bar](#), which describes the action to be executed by the selected menu item or depressed toolbar button, and additional information about the pattern. A check mark appears next to the menu item when the Status Bar is displayed.

Rotation Bar

This toggles the [rotation toolbar](#) between visible (hidden) states.



Tools Commands

Batch Conversion

The batch conversion utility allows the user to convert multiple embroidery files of possibly different types to another embroidery file type. Launching the batch utility initiates a sequence of dialogs that collect the various files to be converted, determine where the converted files should be stored, and choose what the converted file type should be. Options include (1) automatically centering converted patterns; (2) overwriting existing files of the same name; and (3) preserving (in the batch directory) the directory tree structure of the original files.

The Batch pane in the [status bar](#) is enabled when batch conversion is in progress. A progress bar shows the completion status of the submitted job.

Note that batch conversion runs as a background job, so the user may continue editing or viewing patterns even while conversion is in progress.

Detailed instructions for using this utility follow. Open the batch converter and use the Windows Explorer® dialog to select files - or directories of files – that you want to convert. Hold down the Shift (or Control) key to select multiple contiguous (or separate) files. Drag the files – by holding down the left mouse button while you move the mouse cursor over the list box - into the File Conversion list box and drop them there (by releasing the mouse button). You may select Zip file archives containing embroidery files, as well.

When you are finished selecting the embroidery files for conversion, press the "Next" button to reveal the batch conversion dialog. On the first line, you may enter the path of the directory where the converted files will be placed. If you want to choose an existing directory, click the "Browse" button to see a directory tree to choose from. When choosing a conversion directory, you may also check the button "Preserve directory tree", which will store the converted files in the conversion folder with a tree structure similar to the source tree. Alternatively, you may choose the option "Store files in source directory". With this option selected, the converted files will be stored in the same directory (or directories) as the original files. Next, select the file filter type (that is, the type of embroidery file) that the selected files should be converted to by scrolling through the combo box. Finally, select the remaining conversion options by checking the appropriate boxes, and press the "Convert" button to start the batch conversion process. The conversion occurs in the background, so if you have a lot of files to convert, you can continue other editing tasks with **SewWhat!** in the meantime.

When the conversion of the selected files is finished, a batch log file will appear, showing some details of the files that were converted. If you want to save this file, go to the "File, Save As" menu button of Notepad © and enter a new name for the batch log file (the original batch log file will be automatically deleted, in order to preserve disk space).

Shortcuts

Toolbar:
Keys:



CTRL+B

Create D1 Floppy

This Tools menu item allows you to copy Designer 1 (D1) embroidery stitch files (files with the extension .shv) to a floppy diskette, for use with the Husqvarna-Viking Designer 1 © embroidery



machine. The files can also be compressed to a Zip archive file (*.zip format) for subsequent redistribution (by email, for example) or decompression. You may enter an informative name for this set of files in the "Disk Project Title" edit box. This name will be used to uniquely label the Zip archive file and the D1 diskette. Existing D1 floppy disks can be modified by adding (or deleting) files to the various menu lists, as described below. Also, you can choose to view icons of the files in the menu lists (or hide them) by clicking the "Show Icons"/"Hide Icons" button.

The first time this utility is used, a dialog will automatically appear for choosing the default D1 floppy drive location and Zip-archive directory (where the zip files will be stored on the hard drive). You may change these default settings at any time from the [D1 Options](#) item on the [Options menu](#) item.

If you insert a floppy diskette that already contains D1 files and menus, **SewWhat!** will automatically read it and the existing D1 files will appear in their proper menu lists in the D1 disk creation dialog. Any files which are not D1-compatible files will be automatically erased from the diskette prior to writing the new D1 floppy information. It is therefore **not** necessary to use a clean diskette. Note that any files on the diskette that are NOT D1 (*.shv) files will be erased.

The first step in the creation of the D1 Floppy (or Zip archive) is to copy existing D1 embroidery files to the menu folders in this dialog. (The embroidery files must be converted to (.shv) file format prior to using this utility.) Click the "**Browse**" button on the right of the D1 dialog. This will open an Explorer-style window for locating the D1 files to be included in the project and eventually either written to a floppy diskette or Zip archive file. (Alternatively, the standard Windows Explorer window can be opened for file selection. However, the advantage of using the Browse-button Explorer is that only D1 embroidery files will be displayed.) Use the mouse (or arrow keys) to select files in the Explorer window. Hold down the Shift key to select multiple contiguous files (or Ctrl key to select multiple separate files). The selected files can be dragged and dropped into one (or several) of the four menu folders in the dialog. To delete files from the lists, select them with the mouse and press the "Delete" key. It is important to note that the process of copying files to the D1 menu folders **does not move** the original files on your hard drive or CD.

After filling the menu(s) with the desired embroidery files, click the "**Accept**" button on the Explorer dialog. Then click one of the buttons "**Write Floppy**" or "**Write Zip**". This will write the files, together with all the required D1 menu files, to either a floppy disk or a Zip archive file, respectively. At this point, if the floppy disk is not empty and it is not already an existing D1-compatible disk, a message will appear to inform you that all files on the floppy will be deleted if you continue. (Remember that if you write to a zip archive file, the name of the file will be taken from the Project Title and the file will be stored in the default Zip-file directory you chose earlier. **Note:** you must **decompress** any D1 Zip archive files to a **fresh** floppy diskette, in order to use that disk in the Designer 1 machine. Simply **copying** the zip archive files to a floppy disk **will not work!**)

The D1-compatible diskettes or Zip archive files created by **SewWhat!** may be freely distributed, subject to any license restrictions associated with the original pattern files. This explicit license accompanies all D1 diskettes or Zip files created with the **SewWhat!** utility.

Shortcuts

Toolbar:



Sew Lettering


This Tools menu item allows you to add lettering and monogramming (or more generally, any alphabetical or "dingbat" icon) to an embroidery pattern.



The "Add Lettering to Pattern" dialog allows you to (1) choose the font and size of the lettering to be stitched into the pattern; (2) enter the text to be stitched; and (3) select the type of outline stitching (either running, zig-zag satin, or applique) or fill stitch. In addition, there are buttons to Save and Retrieve settings for future use.

Click the Font and Size button to display the standard Windows Font Selection dialog. Font sizes are indicated in points. One point is 1/72 inch (3 points are approximately 1 mm). You can select the font size by clicking on the font size selection (combo) box, or by typing the size (in points) in the font-size edit box. The font family (face name) can be chosen from the font selection (combo) box. Any True Type font can be used. Note in addition to standard alphabetical characters, various iconic symbols (boxes or dingbats) can also be displayed. For example, the font *Holidays MT* in lower case has many interesting icons representing various holidays. The color of the font will determine the thread color used and may also be selected. Choose OK to accept your selections. The font and size will appear in the text box next to the Font and Size button.

Note that the text size refers to the font height (in mm) and text-string width (in mm). These dimensions are indicated below for the text string "Tiger" written in a 72-pt (~24 mm) font size. The light gray grid is the **SewWhat!** grid which has a spacing of 10 mm. The horizontal extent of the string is 47 mm. The indicated string height of 25 mm is *not* just the distance from the top of the "T" to the bottom of the "g", but also includes some blank space (so-called *internal leading*) above the "T", which can be used for accent marks.



Next, the type of stitch used to outline the selected font should be chosen. There are three stitch types available for outlining, and two types of fill stitches. For outlining, a straight (running) stitch, a zigzag (satin) stitch, or appliqué stitch may be used. You may set the length of a running stitch (in 0.1mm units) with the associated up/down arrows. For satin outline stitches, both the length and height of the stitch may be set. To keep a fixed stitch density, you should change these dimensions proportionately with the size of the font. Note that if you resize the text *after* it has been converted to stitches, the stitch density will change in proportion to the amount of resizing. The appliqué stitch is a combination of a running stitch to outline the fabric and a satin (or blanket) stitch to trim the border.

To apply the appliqué, follow these steps:

1. Position the appliqué fabric on the (hooped) base fabric.
2. Baste the appliqué fabric to the base fabric.
3. Stitch color 1, the outline of the letter, to hold the fabric in place along its border.
4. Remove hoop from machine *without moving* the embroidery arm or unhooping.
5. Cut out the appliqué around the stitching line. Cut just outside of, and as close as possible to, the stitching line.
6. Reinsert the hoop onto machine (without moving the embroidery arm) and stitch color 2,



the satin stitch outline.

Either the fil(area)| or satin(column) stitch option will produce a solid filled pattern (rather than an outline). Checking one of the border option boxes will outline the filled pattern with either a straight or satin stitch. The stitch-separation spin control can be used to adjust the fill stitch density from highest (smallest separation, produces a stitch-out with the most stitches) to lowest. Finally, the angle spin control allows you to choose the angle – with respect to the vertical – at which the stitches will be sewn.

It is recommended – especially for wider letters and large fonts – that the underlay stitches box be checked. Underlay consists of sparse satin stitches which are added to the pattern underneath the final fill stitches, to ensure good registration (alignment) of the final stitches by preventing bunching or pulling of the fabric.

The monogramming options apply to any of the various stitch types and can be chosen by clicking on the appropriate icon. For some of the monogram features, additional adjustment of the letter height and/or the letter position can be done with the two scroll-controls located at the bottom of the monogram panel. For example, to increase (decrease) the size of the one enlarged letter, click the "scale factor" spin-control button up (down). To adjust the vertical position of the enlarged letter, click the "Adjust-position" button.

As you type text into the edit box at the top of this dialog, it will appear in the preview box at the bottom of the dialog. You may edit this text (backspace to delete letters) in the edit box. Properties of the text pattern that will eventually be stitched - including its size, the total number of normal stitches and jump stitches - are also displayed. By increasing the length (width) of the stitches, you can reduce the total number of stitches, while maintaining a nearly constant thread length.

To enter a monogram consisting of variable height letters, you will have to enter each letter separately using this dialog box.

Finally, when all text editing is completed, click the "OK" button to sew the text into the pattern file and return to the **SewWhat!** workspace (if none is presently open, a new file will be opened).

Shortcuts

Toolbar:



Sew and Show

The "Sew-and-Show" feature allows the pattern to be viewed on screen as it would appear to be "stitched" in time. This simulates on screen the activity of a real embroidery machine. It is activated either from the main toolbar by pressing the "Sew-and-Show" button, or by selecting the "Sew-and-Show" item on the Tools menu, or by pressing the "Sew" button on the [main toolbar](#) .

Shortcuts

Toolbar:



Keys:

CTRL+W

Center Pattern

This toolbar button or tools menu item can be used to center a pattern in the hoop.



Shortcuts

Toolbar:



Fabric Color

Displays color selection dialog for choosing the "fabric color", which is the background color against which the pattern is shown on the screen. This is helpful for visualizing how a pattern will appear on a given fabric and for selecting appropriate thread colors. You can also press the "Set Default" button to set the fabric color in this dialog as the default color that will be used for all future patterns.

The Fabric Color Palette provides 48 standard colors and permits the addition of another 16 custom colors. Click on the "Define Custom Colors" button to reveal the color picker. Existing custom colors can readily be changed as required.

Shortcuts

Toolbar:



Keys:

CTRL+F

Zoom In

This magnifies the on screen size of the pattern. This might be useful for viewing individual stitches. Note that zooming has no effect on the pattern size (unlike resizing); rather, it only affects the size of the viewed image on screen.

Shortcuts

Toolbar:



Zoom Out

This reduces the on screen size of the pattern. This is useful for viewing at once a larger portion of the design. Note that zooming has no effect on the pattern size (unlike resizing); rather, it only affects the size of the viewed image on screen.

Shortcuts

Toolbar:





Options Commands

Album Filter

This Options menu item will display a dialog for selecting the type(s) of embroidery files that will be displayed by **SewWhat!** when the Album Icon view is visible. The file types – denoted by their particular file extensions – to be displayed can be chosen by clicking their associated check-boxes. For example, to limit the files shown in the album view to types produced for Brother machines, select the check-box labeled *Brother*.

D1 Drives

This Options menu item allows you to select various options used when creating [Designer \(D1\)](#) diskettes (floppy disks) or writing D1 Zip archives. A dialog will appear which displays the removable-media drives detected on your system. Click the drive to use for writing the D1 floppy diskettes. You may also choose the directory for storing any Zip archive files (*.zip) that you create using the D1floppy utility.

File Save

This Options menu item is used to select various options which will be applied when files are saved. These include:

- Default file–type extension. This is the file extension that will appear when the Open/File Save As menu item is selected.
- Various options for splitting files (depending on their type), based on maximum allowable colors or stitches.
- Maximum hoop size. Patterns exceeding this will be automatically resized to fit into the maximum hoop.

Grid

This Options menu item is used to set the thickness and color of the grid lines displayed on the screen.

Hoop Size

This displays the dialog for selecting the hoop size and positioning the hoop on the screen. A choice of units - inches or millimeters - is available. Use the vertical (horizontal) spin control to change the vertical (horizontal) position of the hoop on the screen.

Select from the available hoops for this pattern type from the drop-down list. You may enter a custom hoop size by typing in the edit box. The selected hoop size can be set to be the default for this pattern type by pressing the "Set Default" button (clear the default hoop size with the "Clear

Default" button).

Shortcuts

Toolbar:
Keys:



CTRL+H

Image

This Options menu item displays a dialog for setting the quality (from low quality to hi quality) for saving embroidery file images as JPEG files.

Units

Use this Options menu item to choose either American (inches and yards) or metric (millimeter or meter) units for displaying lengths in **SewWhat!**



Windows Commands

New

Use this command to open a new window with the same contents as the active window. You can open multiple document windows to display different parts or views of a document at the same time. If you change the contents in one window, all other windows containing the same document reflect those changes. When you open a new window, it becomes the active window and is displayed on top of all other open windows.

Cascade

Use this command to arrange multiple opened windows in an overlapped fashion.

Tile

Use this command to arrange multiple opened windows in a non-overlapped fashion.

1, 2, ... command

SewWhat! displays a list of currently open document windows at the bottom of the Window menu. A check mark appears in front of the document name of the active window. Choose a document from this list to make its window active.



Help Commands

Tip of the Day

When **SewWhat!** initially runs, a brief message appears with a helpful suggestion for using this application. By clicking this menu item, you can view these initial "tip of the day" messages whenever the application is open.

You can add your own tips to the "swtips.txt" file and they will appear as additional "Tip of the Day" messages.

Help Topics

Use this command to display the opening screen of Help. From the opening screen, you can jump to step-by-step instructions for using **SewWhat** and various types of reference information.

Once you open Help, you can click the Contents button whenever you want to return to the opening screen.

Auto-Update

Use this command to toggle (turn on/off) automatic updating of **SewWhat** software. When this menu item is checked (unchecked), auto-updating is allowed (prevented). With auto-updating allowed, the **S & S website** will be checked whenever the application is opened (but not more than once daily) for available updates. If there is an update available, the user will be given the opportunity to install it. The installation will *automatically* close the **SewWhat** workspace, remove the older version, install the update, and restart the application.

About SewWhat

Use this command to display the copyright notice, registration information and version number of your copy of **SewWhat!**

Change (History) Log

Use this command to display the history of changes made to **SewWhat**.



Sewing Topics

Resize

Note: It is often helpful to display [grid lines](#) before resizing or moving a pattern.

To move the pattern within the hoop:

1. Select it by clicking anywhere in the pattern with the left mouse button. A resizing rectangle will appear around the pattern, and the cursor will change to a four-headed arrow.
2. To move the pattern, either hold down the left mouse button and drag it to a new position or use the keypad arrow keys.

To resize the pattern:

1. Perform step 1 as above.
2. Position the mouse at one of the resize button of the selection rectangle. The cursor changes to a diagonal two-headed resizing arrow.
3. Move one of the corners (or sides) with the mouse, dragging the pattern in or out to its final desired size. Use the corners to preserve the pattern aspect ratio (relative height to width ratio). Use the side buttons to stretch or shrink the pattern either horizontally or vertically.

Observations:

1. Both these operations affect the size and position of the pattern as it is stitched out. This is in contrast to the [zooming operations](#), which simply change the apparent size of the pattern on the screen without affecting the real stitch-out.
2. Resizing a design in **SewWhat!** does not preserve the stitch density of the design. Therefore resizing a design more than 10 - 15% may not produce satisfactory sewn results (unless a lighter or heavier embroidery thread is used to compensate). Ideally, resizing should maintain the stitch density by adding (or subtracting) stitches.

Rotate

You can use the freehand rotation knob to rotate the selected pattern. Alternatively, use the [rotation toolbar](#) to rotate (counter-clockwise) the selected pattern by 90, 10, or 1 degree increments.

Reflect

On the rotation toolbar, press the reflect radio button to reflect the pattern left to right. To reflect the pattern up-down, first rotate the pattern by 90 degrees.



Dialogs

File Open

The following options allow you to specify which file to open:

File Name

Type or select the name of the embroidery file you want to open. This box lists files with the extension you select in the List Files of Type box. Embroidery files that have been “zipped” into an archive (*.zip file) will appear in their uncompressed format.

List Files of Type

Select the type of file you want to open, depending on the file extension, as described below:

Extension	Manufacturer
.10o	Toyota
.art	Bernina Artista
.csd	Poem, Singer
.dst,dsb,dsz	Tajima
.emd	Elna
.exp	Melco (DOS-Expanded)
.hus	Husqvarna
.jef	Janome, New Home, Memory Craft
.ksm	Pfaff Professional
.pcd	Pfaff 9mm stitches (Prodigy)
.pcq	Pfaff 6mm MAXI stitches
.pcs	Pfaff Home
.pcm	Pfaff on Macintosh
.pes, .pec	Brother, Baby Lock, Bernina Deco
.phb, .phc	Brother
.sew	Kenmore, Elna, Janome
.shv	Viking Designer 1
.sst	Sunstar
.stx	Datastitch
.tap	Happy
.u??	Barudan (?? is a number)
.vip	Husqvarna/New Pfaff
.vp3	Viking Designer SE
.xxx	Singer, Compucon
.zsk	ZSK
.zip	Zip Archive

Choosing a zip archive file that contains one of the preceding sewing pattern files will automatically extract that file to your hard disk when you click the "open" button. Once a file is selected, a preview of its contents is shown in the dialog box.

Drives

Select the drive in which **SewWhat** stores the file that you want to open.

Directories

Select the directory in which **SewWhat** stores the file that you want to open.



File Save As

The following options allow you to specify the name and location of the file you're about to save:

File Name

Type a new filename to save a document with a different name. **SewWhat** adds the extension you specify in the Save File As Type box.

Drives

Select the drive in which you want to store the document.

Directories

Select the directory in which you want to store the document.

Print

The following options allow you to specify how the document should be printed:

Printer

This is the active printer and printer connection. Choose the Setup option to change the printer and printer connection.

Setup

Displays a [Print Setup dialog box](#), so you can select a printer and printer connection.

Print Range

Specify the pages you want to print:

- | | |
|------------------|---|
| All | Prints the entire document. |
| Selection | Prints the currently selected text. |
| Pages | Prints the range of pages you specify in the From and To boxes. |

Copies

Specify the number of copies you want to print for the above page range.

Collate Copies

Prints copies in page number order, instead of separated multiple copies of each page.

Print Quality

Select the quality of the printing. Generally, lower quality printing takes less time to produce.

Printer Setup

The following options allow you to select the destination printer and its connection.

Printer

Select the printer you want to use. Choose the Default Printer, or choose the Specific Printer option and select one of the current installed printers shown in the box. You install printers and configure ports using the Windows Control Panel.

Orientation

Choose Portrait or Landscape.

Paper Size

Select the size of paper that the document is to be printed on.

Paper Source

Some printers offer multiple trays for different paper sources. Specify the tray here.

Options

Displays a dialog box where you can make additional choices about printing, specific to the


type of printer you have selected.

Network...

Choose this button to connect to a network location, assigning it a new drive letter.

Thread Color

The thread color dialog box is shown below. It is shown whenever a color button on the [thread color toolbar](#) is clicked.



Click on one of the "palette" colors in this dialog to select a new thread color to be used for the selected group of stitches. The palette of colors shown is associated with the type of embroidery file being edited. There are different palettes for PES, JEF, and HUS/SHV files. Some other file types allow you to "mix" custom colors, or to choose colors from a Brother-style palette. To mix a custom color, click the "Custom Color" button. This will initiate a dialog for choosing a color with arbitrary values of Red/Green/Blue pigments or Hue/Saturation/Luminance. Note: the custom color option will only be shown for those types of embroidery files that support it (ART, EMB, CSD, PCS, VIP, VP3, XXX). Finally, the recommended Sulky® or Madeira® thread ID is also displayed to help in selecting a thread that closely matches the displayed color.



Toolbars

Main Toolbar

The main toolbar is displayed across the top of the application window, below the menu bar. The toolbar provides quick mouse access to many tools used in **SewWhat!**



To hide or display the main toolbar, choose Toolbar from the View menu (ALT, V, T).

Click	To
	Open a new document.
	Open an existing document. SewWhat displays the Open dialog box, in which you can locate and open the desired file.
	Save the active document or template with its current name. If you have not named the document, SewWhat displays the Save As dialog box.
	Email the active pattern.
	Remove selected pattern from the document and stores it on the clipboard.
	Copy the selected pattern to the clipboard.
	Insert the pattern stored in the clipboard into the active window.
	Undo the last editing operation.
	Print the active document.
	Perform batch conversion of multiple embroidery files.
	Toggle between icon and information view.
	Add Lettering/monogramming to pattern.
	Write files to a D1 readable floppy disk.
	Renders the stitches as they would be sewn (in time) to simulate embroidering on a machine.



Select hoop size to fit pattern.



Select fabric color.



Select ALL embroidery (thread) objects in workspace.



Select NEXT embroidery (thread) object in workspace.



Select PREVIOUS embroidery (thread) object in workspace.



Center pattern in hoop.



Enlarges view on screen (**zoom-in**) without changing pattern dimensions.



Decreases screen size (**zoom-out**) without changing pattern dimensions.

Status Bar

The status bar is displayed at the bottom of the **SewWhat** window. To display or hide the status bar, use the Status Bar command in the View menu.

The left area of the status bar describes actions of menu items as you use the arrow keys to navigate through menus. This area similarly shows messages that describe the actions of toolbar buttons as you depress them, before releasing them. If after viewing the description of the toolbar button command you wish not to execute the command, then release the mouse button while the pointer is off the toolbar button. Furthermore, when moving the mouse over the thread toolbar, the color number of the thread is displayed here.

The right part of the status bar indicate information about the pattern status:


Indicator	Description
BATCH	Shows status of batch job running in background.
LOCATION	X and Y position, in mm, of the top left corner of the pattern, relative to the top left of the hoop (at X=0, Y=0)
ROTATION	The rotation angle, in degrees, of the pattern, measured counter-clockwise from its initial angle (0 degrees).
STITCHES	The number of stitches in the selected pattern.

Sew-and-Show



The *Sew and Show* floating dialog bar allows the user to control certain properties of the real-time pattern stitching feature. User-selectable properties include (1) the **stitch rate** (stitches per second), which may be adjusted to speed-up or slow-down the on screen rendering of the pattern (note: this can be changed even while the pattern is stitching); (2) pattern **stop**, which terminates the sew-and-show rendering; (3) pattern **pause**, to temporarily suspend the rendering until the sew button is pressed to restart the stitching; and (4) pattern **options**, which include auto-pausing (or continuous rendering) after each thread color change. Finally, there is a color-box to indicate the color of the thread being presently stitched.

Title Bar



The title bar is located along the top of a window. It contains the name of the working embroidery "document" as well as the number of stitches and pattern size.

To move the window, drag the title bar. Note: You can also move dialog boxes by dragging their title bars.


A title bar may contain the following elements:

- Application Control-menu button
- Document Control-menu button
- Maximize button
- Minimize button
- Name of the application
- Name of the document
- Restore button

Scroll Bars

These are displayed at the right and bottom edges of the document window. The scroll boxes inside the scroll bars indicate your vertical and horizontal location in the document. You can use the mouse to scroll to other parts of the pattern.

Print Preview



The print preview toolbar offers you the following options:

Print



Bring up the print dialog box, to start a print job.

Next Page

Preview the next printed page.

Prev Page

Preview the previous printed page.

One Page / Two Page

Preview one or two printed pages at a time.

Zoom In

Take a closer look at the printed page.

Zoom Out

Take a larger look at the printed page.

Close

Return from print preview to the editing window.

Rotation



This toolbar allows the user to select the angle increments by which the selected pattern will be [rotated](#) in a counter-clockwise direction, or to [reflect](#) the pattern about the vertical axis (Reflect L/R) or the horizontal axis (Reflect T/B).

Thread Color



The floating thread color toolbar is used to display a list of the thread colors (in order of appearance) in the current pattern. (A slider bar will appear if more colors exist than can be displayed in this bar. The user may then move the slider to display selected portions of the color list.) By clicking with the left mouse button on a colored button on this toolbar, the [thread color dialog box](#) will appear. After choosing a new color from this dialog, the thread color will be changed on screen. The new color will be permanently stored only when the pattern is saved.



Miscellaneous

Context Help

Use the Context Help command to obtain help on some portion of **SewWhat!**. When you choose the Toolbar's Context Help button, the mouse pointer will change to an arrow and question mark. Then click somewhere in the **SewWhat!** window, such as another Toolbar button. The Help topic will be shown for the item you clicked.

Shortcut

Toolbar:



Keys:

SHIFT+F1

Purchase SewWhat

You may run the installer for **SewWhat** from the S & S website:

<http://sandscomputing.com>

Just click the **SewWhat** link at the top of the main page, and then scroll down to the "Download Links" table. On the left are links for the 32 and 64-bit installers. Run the one appropriate for the Operating System on your computer.

There is a 30 day DEMO period during which you may run the software (with only a restriction on the number of file saves during that time). After that, you can either uninstall the software or purchase from the "Add-to-Cart" button to the right of the download links on the **SewWhat** web page. After you purchase the license, the registration information will be emailed to you and you can register the DEMO to make it a licensed copy. Note: you DO NOT have to uninstall the DEMO if you want to keep the software, but only register it after purchasing the license.